
MediaCityUK





GeniePoint Network – Charger User Guide

How to use the charger:

If you are a registered GeniePoint Network user, and have an RFID card, place it against the reader and follow the instructions on the charger display panel.

If you are registered on the GeniePoint Mobile Web App, login in and tap "NEARBY" to select the charger you require, then tap Charge then Start to begin the charging session.

If you are not already registered, please go to www.geniepoint.co.uk to register for a GeniePoint Network account. Don't forget to register a valid payment card and ensure you have sufficient credit to start your charge session.

Costs:

The cost to use the Media City Chargers is: £0.30p per kilowatt hour

After charging, please move your vehicle to permit others to use the charger.